

Solo Digit Instructions - NEW:

- 1. Plug the detachable power cord into the back of the unit. Then insert the plug into your electrical outlet. At this time, the display will show 'STDBY', which indicates that the unit is on Standby.
- 2. Press the 'Power' button to turn the unit on. The initial temperature that is displayed is 310°F. The screen will display two temperatures bottom one (in red) is the desired temperature and top one (in green) is the current temperature of the unit.
- 3. Use the 'Up' and 'Down' buttons to regulate the temperature.
- 4. When current temperature reaches the desired temperature (temperature in green light will be same as temperature in red), it indicates the unit is now ready to use.
- 5. Now load your aromatherapy blends against the screen in the whip. Then connect the whip to the unit and draw from the mouthpiece on the other end of the whip (slower draws maximize the effect).

Helpful Tips:

- ➤ Load the vapor whip to about 1/3 full with finely grinded aromatherapy blends.
- > Start vaporizing at a lower temperature and work your way up as you feel that your aromatherapy blends are losing moisture. The starting temperature should be around 340°F.
- > Detach the whip right after use to conserve your aromatherapy blends.

Important:

- Turn the unit off when not in use (turning it off every 20 minutes for about 5 minutes is ideal). This will prolong the life of the heating element and maximize the life of your unit.
- It automatically goes on standby if no buttons are pressed for 20 minutes.
- Use the aroma bulb when using essential oils.
- Do not leave the whip attached to the unit, when not in use.
- Always use a surge protector.
- Materials are fully vaporized when the color has changed to light brown and smell lightly roasted. If you wish to use your aromatherapy blends a little more, use the reed diffuser to stir your blends and use again.

How to replace the screen?

To replace the screen, place the screen in the glass part. Now, use the wooden stick from the narrow end of the glass part and your index finger from the other. Push the screen with your finger till it fits into the groove.

How to clean the glass parts?

The glass parts attached to the whip can be cleaned with a glass cleaner. The hose can either be cleaned by soaking in boiling water with white vinegar (the cleaning sticks provided with the unit can be used as well) or it can be replaced (a new food grade hose can be purchased from a hardware store.